

TOOL MIX & MATCH / CHAIR MIX & MATCH 20829, 20818

| NR NO | DETAIL ITEM | NIMETUS DESCRIPTION | KOGUS QTY |
|-------|---|---|-----------|
| A |  | M6x45mm JCBC KRUUVI M6x45mm JCBC SCREW | 10 |
| B |  | VEDRUSEIB SPRING WASHER | 10 |
| C |  | SEIB WASHER | 10 |
| D |  | M4x32mm KRUUVI M4x32mm SCREW | 6 |
| E |  | M4 6-KANTVÕTI M4 ALLEN KEY | 1 |

| | | |
|---|---|---|
|  <p>ESIMENE JALG 2TK FRONT LEG 2PCS</p> |  <p>ALUMINE RAAM LOWER FRAME</p> <p>ISTME RAAM BOX SEAT</p> <p>SELJATUGI BACK PANEL</p> <p>SAMM 1/STEP 1</p> |  <p>ESIMENE JALG FRONT LEG</p> <p>SAMM 2/STEP 2</p> |
| |  <p>SELJATUGI 1TK BACK PANEL 1PC</p> | |
|  <p>ISTMERAAM 1TK BOX SEAT 1PC</p> |  <p>ISTE 1TK CUSHION SEAT 1PC</p> <p>SAMM 3/STEP 3</p> |  <p>KEERAKE PÄRIPÄEVA ROTATE CLOCK WISE</p> <p>ISTE CUSHION SEAT</p> |
|  | | |

TOOL MIX & MATCH / CHAIR MIX & MATCH 20829, 20818

SAMM 1

Kinnitage istmeraam ja alumine raam seljatoe külge. Kasutage kinnitamiseks M6x45mm kruvisid, vedruseibe ja seibe (x6).

SAMM 2

Kinnitage esimesd jalad istmeraami külge. Kasutage kinnitamiseks M6x45mm kruvisid, vedruseibe ja seibe (x4).

SAMM 3

Kinnitage alumine raam esimeste jalgade külge. Kasutage M4x32mm kruvisid (x2).

Asetage iste tagurpidi laua peale ja paigaldage eelnevalt kokkupandud tooliraam istme peale. Kinnitage iste tooliraami külge M4x32mm kruvidega (x4).

M4x32mm kruvide keeramiseks on tarvis kruvikeerajat. **Kruvikeeraja ei kuulu komplekti.**

STEP 1

Screw on the box seat and lower frame to back panel with M6x45mm screw, spring washer, and washer (x6).

STEP 2

Following by tightening the front leg with an M6x45mm screw, spring washer, and washer (x4).

STEP 3

Screw on the lower frame with an M4x32mm screw (x2).

Put the cushion seat onto the table then turn around the chair and screw on with an M4x32mm screw to the cushion seat (x4).

*Screwdriver required. **A screwdriver is not included.***