

















KOKKUPANEKUJUHEND / ASSEMBLY INSTRUCTION

OSADE LOETELU / PARTS LIST							
A	ISTE / SEAT		1	D	POLT / BOLT M6X20		2
B	JALG / LEG		1	E	METALLSEIB M6 METAL WASHER M6		2
C	VÕTI M6 ALLEN WRENCH M6		1				




KOKKUPANEKUJUHEND / ASSEMBLY INSTRUCTION


OSADE LOETELU / PARTS LIST

A	LAUAPLAAT TABLE RIM		1	F	POLT / BOLT M8x50		8
B	TUGIJALG SUPPORTING TUBE		1	G	METALLSEIB M6 METAL WASHER M6		10
C	ALUS TABLE BASE		1	H	METALLSEIB M8 METAL WASHER M8		8
D	POLT / BOLT M6x25		8	I	VÕTI M6 ALLEN WRENCH M6		1
E	POLT / BOLT M6x35		2	J	VÕTI M8 ALLEN WRENCH M8		1


SAMM / STEP 1



SAMM / STEP 2




SAMM / STEP 3



Laua tõstmiseks vajutage nuppu ja hoidke all.
Press and hold the button as the table rises.

SAMM / STEP 4



Laua langetamiseks vajutage nuppu ja suruge käega lauaplaati kergelt alla.
Press the button as the table descends and press down with your hand on the center of the table as shown.