


OLULINE

Kui toode on juba kokku pandud, siis ei ole seda võimalik uuesti lahti võtta.

IMPORTANT

Once installed, the product can not be detached.



* Kontrollige enne kokkupanemist kõik osad üle. Kui mõni osa on puudu või märkate muid puudusi, võtke ühendus müüjaga.

* Järgige hoolikalt kokkupanekujuhendit.

* Leidke kokkupanemiseks tasane ja puhas pind.

* Elektritööriistadega töötades, kasutage alati kaitseprille.

* Mõni osa võib olla teravate äärtega. Kasutage kokkupanemisel töökindaid.

Tulekahju korral ärge püüdke kunagi polüpropüleenist esemeid veega kustutada.

* Check all parts before assembly.

If you have any problems or discover any missing parts, please contact customer service.

* Follow the assembly instructions carefully.

* Assemble on a flat and clean surface.

* Wear safety-goggles when using power tools


* Some parts may contain sharp edges.

Wear protective gloves.


In case of fire, do not attempt to extinguish any burning polypropylene with water.

1


ODADE LOETELU / PARTS LIST



(X1)




(X1)




(X3)

2


1



(X1)




(X1)



2




(X3)




3

3




4



4

5



5

Ärge seiske laua kaane peal püsti.

Do not stand on the lid.

141A