










Assembly Instruction





Panel No	Panel Sizes	Quantity
1	1500*400*16	1
2	1500*400*16	1
3	268*399*16	2
4	268*360*16	2
5	1476*278*5	1


Panel No	Panel Sizes	Quantity
6	472*350*16	2
7	481*350*16	1
8	487*264*18	1
9	487*264*18	1




Fittings



A=16




B=16




C=16




D=16



E=8




F=1



M6*16


G=19




I3=4




H=1




J-1=4



J-2=1



L=12



U=2




Z1=19




Z2=19


STEP 1




STEP 2




STEP 3




STEP 4




STEP 5




STEP 6







STEP 7




STEP 8




STEP 9




STEP 10



STEP 11




STEP 12



Finish

新-利尼双门电视柜W150邮购包装



Panel No		Panel Sizes	Quantity
10	护角	50*50*50	8
11	泡沫	1500*400*10	2
12	泡沫	440*105*40	2
13	泡沫	1500*105*20	2
14	泡沫	1500*50*20	1
15	泡沫	350*75*15	1
16	泡沫	427*70*35	2
17	泡沫	1072*135*15	1
18	泡沫	265*98*15	1
19	泡沫	536*40*15	1
20	纸盒	内径1590*450*115	1