


Panel No	Panel Sizes	Quantity
1	1600*100*16	1
2	1600*374*16	1
3	318*373*16	2
4	318*373*16	2
5	493*350*16	2

Panel No	Panel Sizes	Quantity
6	539*350*16	1
7	506*328*5	2
8	552*328*5	1
9	329*530*25	1
10	329*530*25	1




Fittings



A=16




B=16




C=16




D=16



E=12




F=1




M6*16

G1=8



M6*30


G2=4



I1=4




H=1



J-1=2


J-2=2



L=12




Z1=4




Z2=4


STEP 1




STEP 2




STEP 3




STEP 4




STEP 5




STEP 6




STEP 7




STEP 8




STEP 9




STEP 10




STEP 11



STEP 12



汉普顿电视柜三胺邮购包装图



Panel No		Panel Sizes	Quantity
11	护角	50*50*50	8
12	泡沫	1600*400*10	2
13	泡沫	440*125*40	2
14	泡沫	1600*125*20	2
15	泡沫	500*20*15	2
16	泡沫	400*20*20	2
17	泡沫	400*30*15	4
18	泡沫	50*40*20	2
19	泡沫	130*50*20	2
20	泡沫	328*15*15	1

Panel No		Panel Sizes	Quantity
21	泡沫	328*45*10	1
22	泡沫	566*22*15	1
23	泡沫	1060*50*30	1
24	泡沫	350*27*15	1
25	泡沫	372*327*15	1
26	泡沫	1060*70*25	1
27	泡沫	1600*26*30	1
28	纸盒	内径1690*450*135	1