








Assembly Instruction






Panel No	Panel Sizes	Quantity
1	1200*1200*40	1




Fittings




M6*16

G1=4




M4

H=1



M6*25

G2=16




J-1=4

J-2=1




Z1=16






Z2=16


STEP 1



STEP 2




STEP 3




Finish

温哥华餐桌W120包装2-1



Panel No		Panel Sizes	Quantity
2	护角	50*50*50	8
3	泡沫	1200*1200*10	2
4	泡沫	1280*60*40	2
5	泡沫	1200*60*40	2
6	三角泡沫	351*351*40	4
7	纸盒	内径1290*1290*70	1

温哥华餐桌W120包装2-2



Panel No		Panel Sizes	Quantity
8	护角	50*50*50	8
9	泡沫	720*465*20	2
10	泡沫	505*200*40	2
11	泡沫	725*200*20	2
12	泡沫	230*160*100	2
13	泡沫	550*160*100	1
14	纸盒	内径815*515*210	1