








Assembly Instruction






Panel No	Panel Sizes	Quantity
1	1600*400*16	1
2	1284*400*16	1
3	304*400*120	1
4	304*400*120	1
5	479*420*36	1
6	479*420*36	1
7	288*357*16	1
8	288*357*16	1

Panel No	Panel Sizes	Quantity
9	418*350*16	2
10	409*350*16	1
11	1296*298*5	1
12A/12B	425*282*16	3
13	1286*60*16	1
14	1286*100*16	1
15	152*60*16	2




Fittings



M6*40mm

A1=32



Φ8*40mm

A2=4



Φ8*30mm

B=36




Φ15*12mm

C=32




Φ21mm


D=32



E=10




F2=2




M4mm

H = 1




M7*50mm

Q=8




L=12




V2=6

I2=2



V2=6





I3=4




V1=2

K=3


1




2




3




4




5




6




7




8




9




10




11




12




13








14




15








18



Finish


墨本三门电视柜W160 邮购包装图 1/2



Panel No	Panel Sizes	Quantity
柜体外径	1600*400*70	
纸箱	1690*450*100	
18	护角 50*50*50	8
19	泡沫 440*90*40	2
20	泡沫 1600*400*10	2
21	泡沫 1600*90*20	2
22	泡沫 400*316*15	1

Panel No	Panel Sizes	Quantity
23	泡沫 1284*240*15	1
24	泡沫 400*16*10	1
25	泡沫 288*41*15	1
26	泡沫 92*60*15	1
27	泡沫 1243*50*15	1
28	泡沫 400*28*15	1
29	泡沫 288*41*15	1

墨本三门电视柜W160 邮购包装图 2/2



Panel No	Panel Sizes	Quantity
柜体外径	480*420*360	
纸盒	570*470*390	
30	护角 50*50*50	8
31	泡沫 460*380*40	2
32	泡沫 480*420*10	2
33	泡沫 480*380*20	2

Panel No	Panel Sizes	Quantity
34	泡沫 420*240*50	1
35	泡沫 240*126*100	2
36	泡沫 304*240*20	1
37	泡沫 420*55*50	1
38	泡沫 425*138*50	1